

**CORPORATE HEADQUARTERS & SALES**

27001 Agoura Road, Suite 100  
Calabasas Hills, CA 91301  
Toll-Free: (800) 333-3136  
Tel: (818) 880-8060  
Fax: (818) 880-1144

**CHICAGO**

870 Greenleaf Avenue  
Elk Grove Village, IL 60007  
Toll-Free: (800) 766-4939  
Tel: (847) 806-1340  
Fax: (847) 806-0296

**ATLANTA**

2865 N. Berkeley Lake Road, Suite 4  
Duluth, GA 30096  
Toll-Free: (800) 922-5880  
Tel: (770) 232-1878  
Fax: (770) 232-7133

**MANUFACTURING - LAS VEGAS**

4855-D W. Harmon Avenue  
Las Vegas, NV 89103

**ADDITIONAL OFFICES**

Phoenix, AZ • Philadelphia, PA

**Warning:** *In areas of extreme fluctuations in weather conditions and temperatures, there can be problems with the sun's heat on the clings causing the windows to expand or contract to quickly, which may cause damage to the window.*

**HI-STAT®**

**APPLICATION & REMOVAL TECHNIQUES**

**APPLICATION SURFACE:**

Hi-Stat® may be applied to a variety of smooth polished surfaces such as glass, plastic, chrome, and high gloss smooth, painted surfaces.

**SURFACE PREPARATION:**

For proper adhesion the surface must be clean and dry. This product will not adhere properly to grease, oil, or dirt.

- Mineral spirits, heptane or V.M. & P naphtha can be used to remove grease and oil.
- Mild soaps or detergents warm water and soft cloth will clean the surface prior to application.
- An ammonia-based window cleaner must be used on all glass surfaces.

**APPLICATION TEMPERATURE:**

For best results, application surface and material should be at 30° F or above.

**APPLICATION METHODS:**

Wet Method - This application technique is recommended for all Hi-Stat® decals

- Prepare a wetting solution of two or three teaspoons of liquid household detergent in one gallon of cold water.
- Remove the decal from the liner and lay decal on a clean, flat surface with the side up which will be adhered to the surface.
- Flood the application surface with wetting solution, (alternate method – wetting solution can be sprayed directly on the substrate).
- Place the cling in contact with the application surface. The wetting solution will allow the decal to be slid across the application surface for positioning purposes.
- Once the material is in position, roll the water out, working from the center of the decal to the edges. Use a rubber roller or a squeegee.
- Use paper towels to blot any excess moisture. Rub the edges to ensure the clings have adhered properly.
- After 24 hours the window may be washed, but do not use a squeegee.

**REMOVAL:**

This product can be easily and cleanly removed and reused. Decals need to be stored on the liner in a clean, dry environment.

**REUSE:**

When reusing decals, if adhesion seems low, dip decals in warm water to increase adhesion, then apply.