



**Your Consistent Source for  
Pressure-Sensitive Materials**

*CORPORATE HEADQUARTERS & SALES*

27001 Agoura Road, Suite 100  
Calabasas Hills, CA 91301  
Toll-Free: (800) 333-3136  
Tel: (818) 880-8060  
Fax: (818) 880-1144

*CHICAGO*

870 Greenleaf Avenue  
Elk Grove Village, IL 60007  
Toll-Free: (800) 766-4939  
Tel: (847) 806-1340  
Fax: (847) 806-0296

*ATLANTA*

2865 N. Berkeley Lake Road, Suite 4  
Duluth, GA 30096  
Toll-Free: (800) 922-5880  
Tel: (770) 232-1878  
Fax: (770) 232-7133

*MANUFACTURING - LAS VEGAS*

4855-D W. Harmon Avenue  
Las Vegas, NV 89103

*ADDITIONAL OFFICES*

Phoenix, AZ • Philadelphia, PA

## **Walk-On Graphics® Installation Instructions**

Recommended floor surfaces for applying Walk-On Graphics:

- Tile Floors
- Ceramic Tile
- Sealed Concrete
- Sealed Wood
- Waxed Vinyl

Floor surfaces must be clean, secure and in good condition.

### ***Applying Floor Graphics***

Remove the release liner from the back of the graphic and position it on the desired location of the floor. Lift one edge of the decal. Using a squeegee with overlapping strokes, apply pressure from the middle toward the edge of the decal.

If the decal is large, it is recommended to spray the floor with water mixed with a few drops of liquid soap and follow the above procedure. It is very important that all edges and corners are applied with firm pressure. When more than one panel is used, butt the edges together. Never overlap the decals.

After application is completed, do not polish decals or surrounding floor for 24 hours. If the edges lift at all from the floor, the decal must be removed immediately and replaced. This is to prevent any accident or tripping.

### ***Maintenance***

Walk-On Graphics should be maintained using normal floor maintenance procedures.

### ***Removal***

Remove the Walk-On Graphics decal by lifting one edge and pulling at a sharp angle using short sharp strokes until the decal is up. If the decal as applied to a waxed floor, it is recommended that the floor should be rewaxed.